## 950CB, 953CB and 956CB Security+® remote controls work with the following models.

The following models have a Red or Orange learn button:

1200	6200-2DB	8200-2	4620	7902K	PD200	PD420	PD212	WD822K
2200	6200-2K	8200-2K	4640	9902	PD200-2	PD420-2	PD610	WD912K
4200	7220	9200	4640-2	9950	PD600	PD460	PD612	WD922K
6200	7420	9200-2K	4640-2K	9960	PD600-2	CG40	PD612K	PD460-2
6200-2	8200	9500-3K	7902	PD100	PD600-2K	PD210	PD752	

## **Programming Security+® Remote Controls**

Following is a set of instructions for programming your current remote control or adding an additional remote control.







